

**hameco**

# HA-35-B speakerphone



## User Manual

## CONTENT

1.	Welcome .....	2
2.	Speaker overview.....	2
2.1.	Turn on the hameco speakerphone HA-35-B.....	3
2.2.	Charging the hameco speakerphone HA-35-B .....	3
3.	Connecting.....	4
3.1.	Connecting to a PC .....	4
3.2.	Connecting to a mobile device (bluetooth) .....	4
4.	How to use the hameco speakerphone HA-35-B .....	5
5.	How to care for your hameco speakerphone HA-35-B.....	6
6.	Product disposal .....	7


## 1. WELCOME

Thank you for purchasing the hameco speakerphone HA-35-B. We hope you will enjoy it!

### **hameco speakerphone HA-35-B features:**


- Answer, end and mute calls.
- Connect to computer via USB.
- Connect wirelessly to a mobile device via Bluetooth.
- Portable design.
- Omni-directional microphone.
- Wideband audio for exceptional sound quality.
- LED indicator.

## 2. SPEAKER OVERVIEW





## 2.1. TURN ON THE HAMECO SPEAKERPHONE HA-35-B

- Plug the Hameco speakerphone HA-35-B USB cable into any available USB port on your computer to turn on the phone, or
- Press and hold (3 secs) the On/Off button to turn the hameco speakerphone on or off.



## 2.2. CHARGING THE HAMECO SPEAKERPHONE HA-35-B

Plug the hameco speakerphone HA-35-B USB cable into the 5V power adapter or any available USB port on your computer to charge the battery. The green light flashes when charging, and the green light is on when fully charged.




Note: The product should be charged when first used.

### 3. CONNECTING

#### 3.1. CONNECTING TO A PC

- Plug the hameco speakerphone HA-35-B USB cable into any available USB port on your computer.
- Select the hameco speakerphone "HA-35-B" as the default audio device in the Windows Control Panel sound settings, and in your softphone audio settings.









#### 3.2. CONNECTING TO A MOBILE DEVICE (BLUETOOTH)

- Press and hold (1 sec) the Bluetooth button on the hameco speakerphone until the Bluetooth LED flashes blue. After the pairing is successful, the Bluetooth LED is bright blue.
- Enable Bluetooth on your mobile device, and select the hameco speakerphone "HA-35-B" from the list of available Bluetooth devices.



## 4. HOW TO USE THE HAMECO SPEAKERPHONE HA-35-B

	On/Off	Press and hold (3 secs) the On/Off button until the blue light flashes
	Answer/End call	Press the Answer/End call button
	Speaker volume	Press the Volume up or Volume down button
	Connect with new Bluetooth device	Press and hold (1 secs) the Bluetooth button to connect with a new Bluetooth device
	Reconnect/disconnect with Bluetooth device	Press the Bluetooth button to re-connect/disconnect with a Bluetooth device
	Mute microphone	Press the Mute microphone button



## 5. HOW TO CARE FOR YOUR HAMECO SPEAKERPHONE HA-35-B

- Always store the hameco speakerphone HA-35-B with the power off and safely protected.
- Avoid storage at extreme temperatures (above 70°C/158°F or below -20°C/-4°F). This can shorten battery life and may affect operation. High temperatures may also degrade performance.
- Do not expose the hameco speakerphone HA-35-B to rain or other liquids.

## 6. PRODUCT DISPOSAL

### Safety

For your own safety, this product should only be used with CE and RoHS approved equipment. Using this headset with non-approved equipment would void the warranty of this product.

### Disposal of your product

Municipal waste stream. Old appliances must be collected separately in order to optimise the recovery and recycling of the materials to reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation that when you dispose of the appliance, it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.

